





Sky
Elevator
www.sky-elevator.com


NORMAL TRAVEL



INSPECTION TRAVEL



ENCODER CONNECTIONS



L01 : (4) ENCODER SELECTION (P/R)
L02 : ENCODER PULSE (P/R)

F/7.5.5.02.21

This document is a sample for applications. All information contained in these materials are subject to change by SKY ELEVATOR without notice. SKY ELEVATOR assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.

FUJI FRENIC LIFT SERIES INVERTER OPERATION DIAGRAM				
SKY ELEVATOR	SERIES	FUJI	DRW.	SKY
	PROJ.	FJ005	APPRV.	SKY
	REV.	00	DATE	20 APR 09